

PR-P05, 09

Контроллер

| | |
|-----------|---|
| +12B | 1 |
| GND | 2 |
| W0/SIG | 3 |
| W1/SIG | 4 |
| LED-G/SIG | 5 |
| LED-R | 6 |
| Beep/ADR | 7 |
| Secure | 8 |

